

Durham Research Online

Deposited in DRO:

14 August 2018

Version of attached file:

Accepted Version

Peer-review status of attached file:

Peer-reviewed

Citation for published item:

Mileghem, Seger Van and Borggraeve, Wim M. De and Baxendale, Ian R. (2018) 'A robust and scalable continuous flow process for glycerol carbonate.', *Chemical engineering and technology*, 41 (10). pp. 2014-2023.

Further information on publisher's website:

<https://doi.org/10.1002/ceat.201800012>

Publisher's copyright statement:

This is the peer reviewed version of the following article: Mileghem, Seger Van, Borggraeve, Wim M. De Baxendale, Ian R. (2018). A Robust and Scalable Continuous Flow Process for Glycerol Carbonate. *Chemical Engineering Technology* 41(10): 2014-2023, which has been published in final form at <https://doi.org/10.1002/ceat.201800012>. This article may be used for non-commercial purposes in accordance With Wiley-VCH Terms and Conditions for self-archiving.

Additional information:

Use policy

The full-text may be used and/or reproduced, and given to third parties in any format or medium, without prior permission or charge, for personal research or study, educational, or not-for-profit purposes provided that:

- a full bibliographic reference is made to the original source
- a [link](#) is made to the metadata record in DRO
- the full-text is not changed in any way

The full-text must not be sold in any format or medium without the formal permission of the copyright holders.

Please consult the [full DRO policy](#) for further details.

Supporting Information for

A robust and scalable continuous process for the synthesis of glycerol carbonate from glycerol and dimethyl carbonate

Segeer Van Mileghem,^{a,b} Wim De Borggraeve^b and Ian R. Baxendale^{a*}

^a Department of Chemistry, University of Durham, South Road, Durham, DH1 3LE, United Kingdom.

E-mail: i.r.baxendale@durham.ac.uk

^b MolDesignS, Department of Chemistry, University of Leuven (KUL), Celestijnenlaan 200F, B-3001 Heverlee, Belgium


Preparation of catalysts	2
General procedure for the synthesis of homogeneous catalysts	2
Tetraethylammonium piperidine-2-carboxylate	2
Tetraethylammonium prolinat	2
Tetraethylammonium picolinate	2
Synthesis of heterogeneous catalysts.....	Error! Bookmark not defined.
Polymer supported piperidine-2-carboxylate.....	2
Calculation of relative flow rate for heterogeneous continuous column experiments	3
Calibration curves for glycerol and glycerol carbonate	4
Standard GC Chromatogram.....	5
NMR spectra	6

Preparation of catalysts

General procedure for the synthesis of homogeneous catalysts


Catalysts were synthesized via simple acid-base neutralization reactions. A slight excess of carboxylic acid (1.1 equiv.) was added to an aqueous solution of tetraethyl ammonium hydroxide. The mixture was then stirred at room temperature for 2 h. After evaporation of water at 60 °C under reduced pressure, the residue was washed with methanol. Excess methanol was removed *in vacuo* after filtration and the residue was dried overnight on a high vacuum line.

Tetraethylammonium piperidine-2-carboxylate




The title compound was prepared using the general procedure and all analytical data were found to be in accordance with the literature.¹

Tetraethylammonium prolinates




The title compound was prepared using the general procedure and all analytical data were found to be in accordance with the literature.¹

Tetraethylammonium picolinate



The title compound was prepared using the general procedure and obtained as a yellow solid. ¹H-NMR (300MHz, D₂O, ppm): δ 8.55 (d, *J* = 3.5 Hz, 1H), 7.96 (td, *J* = 7.7, 1.6 Hz, 1H), 7.90 (d, *J* = 7.7 Hz, 1H), 7.56 – 7.50 (m, 1H), 3.23 (q, *J* = 7.3 Hz, 7H), 1.28 – 1.19 (m, 11H).

Polymer supported piperidine-2-carboxylate



Ambersep® 900 Hydroxide form resin (2 g, available from Sigma Aldrich) was added to an RBF containing pipecolic acid (1.3 g, 1.1 equiv.) in methanol (20 mL). The flask was shaken overnight at room temperature (orbital shaker). The polymer beads were filtered, washed with methanol and dried overnight under vacuum.

Calculation of relative flow rate for heterogeneous continuous column experiments

When using 3.5 equivalents of DMC, the following ratio should be achieved when mixing:

$$\frac{3.5 \text{ mol DMC}}{1 \text{ mol glycerol}} = \frac{315 \text{ g DMC}}{92 \text{ g glycerol}} = \frac{294 \text{ mL DMC}}{73 \text{ mL glycerol}} = 4.03$$

Note that this result is the required volume ratio when using both *neat* DMC and *neat* glycerol. This result changes when a solution of glycerol (5M) in methanol is used.

Therefore, the volume percent of glycerol is:

$$5 \text{ M} = \frac{5 \text{ mol glycerol}}{1 \text{ L}} = \frac{460 \text{ g glycerol}}{1 \text{ L}} = \frac{365 \text{ mL glycerol}}{1 \text{ L}} = 0.365$$

Hence the relative flow rate becomes:

$$4.03 * 0.365 = 1.47$$

The relative flow rate of neat DMC should be about 1.47 times the flow rate of glycerol (5 M) in MeOH when 3.5 equivalents DMC are desired.

Calculation and assumptions for Space Time Yield calculations (STY)

The column reactors used in the construction of the flow reactor are Omnifit (10 mm i.d. x 100 mm).

This would equate to a theoretical maximum internal volume of 7.85 mL per reactor. For a reaction of 5 M glycerol in MeOH at a flow rate of 2 mL/min (120 mL/h) using two columns and an isolated yield of 75% the STY would be calculated as follows:



$$\text{Throughput g/h} = 120 \text{ (Rt)} \times 118.09 \text{ (Mw)} \times \frac{5 \text{ (M)}}{1000} \times 0.75 = 53.1$$

$$\text{STY} = \frac{1000 \text{ (L)}}{15.7 \text{ (Rv)}} \times \frac{53.1}{1000} = 3.38 \text{ kg per L per h}$$

Rt = residence time, Mw = molecular weight of the product, Rv = reactor volume.


Calibration curves for glycerol and glycerol carbonate

Several samples were prepared for following GC-MS experiment. Glycerol was dissolved in MeOH (0.113 M) and serial diluted to have samples in between 0.1 M and 0.001 M, the typical concentration range for prepared GC-MS samples. In the same way glycerol carbonate samples were prepared. The same response curve for peak area in function of concentration was obtained for both glycerol and glycerol carbonate. This was considered sufficient for estimation of GC yield, conversion and selectivity.






Standard GC Chromatogram

Comment	RemoteAnalyzer
Data Type	Centroided Mass Spectrum
Date	06 Jan 2016 13:19:57
Inlet Model	Other Probe
Ion Mode	CI-
Number of Scans	2400
Operator	Admin
Time Range	2.200-10.197



NMR spectra





References

- [1] Y. Zhou, F. Ouyang, Z. B. Song, Z. Yang and D. J. Tao, *Catalysis Communications* **2015**, *66*, 25-29.